

## Series 884: Setting Instructions

OkSolar Timer

### Set Time and Day

Slide Set switch to ☉ press 1...7 button until arrow points to the correct day (1=Monday). Press h then m buttons to set correct time. PM indicator shows noon to 11:59 PM. Slide Set switch to Run. Clock colon will blink.

### Set Switch “On” Cycle

Slide Set switch to ☉. A “1” indicates the first switch cycle and a “Bulb” indicates a switch-on (circuit closes). Press 1...7 button until arrows point to selected day(s) for this cycle. Press h and m buttons to show switch-on time, noting PM indicator.

### Set Switch “Off” Cycle

With Set switch at ☉, press ☉ button, note switch cycle number changes to “2” and bulb blanks, indicating switch-off (circuit opens). Press 1...7 button to match day(s) set for switch cycle “1”. Press h and m buttons to select switch-off time.

### Autorun

Slide Set switch to Run and Mode switch to Auto, switching begins with next switch-on set time.

### Override “On”

Slide Mode switch to I. Switch remains on indefinitely (circuit closed).

### Override “Off”

Slide Mode switch to O. Switch remains off indefinitely (circuit open).

### Skip Cycle

In automatic run mode, press ↔ button. The next calendar day is skipped.

### Setting ERROR

If EEE appears, a setting error exists. The switch cycle number in error is shown. Slide set switch to ☉, press ☉ button until cycle is shown, review this and the following setting to correct error, slide set switch to Run.

### Clear any setting

Setting slide set switch to ☉, press ☉ button to show switch cycle to clear. Press the (P) button and the skip (x) button simultaneously.

### Clear All

To erase all settings, press R.